Assembly Instructions

Matrix Tablet Arm

August 2015



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5

1. Slide tablet arm brackets over legs of chair, starting at top of chair, easing downward (Figure 1).
2. It may be necessary to tap in place with a rubber mallet (Figure 2).
3. When bottom rod of tablet arm touches chair frame, secure by snapping clamp onto frame. Clamp should be placed with protruding lip toward bottom of frame (Figure 3 & 4).
4. Make sure that clamp is located between weld spots at underside of chair (Figure 4).
5. A tap with a rubber mallet may be necessary to secure clamp. This should join rod and frame together to complete tablet arm assembly (Figure 5).

Removing Tablet Arms

In order to remove tablet arms, pry clamp free with screwdriver. Then pull up on rear of tablet arm, loosening back end first. Pivot tablet arm structure toward front of chair and remove.

Note: Failure to follow this removal procedure when chair is upholsterd will result in damaged upholstery.

CAUTION

Assemble units as described herein only. To do otherwise may result in instability. All screws, nuts and bolts must be tightened securely and must be checked periodically after assembly. Failure to assemble properly, or to secure parts may result in assembly failure and personal injury.

1330 Bellevue Street • P.O. Box 8100 • Green Bay, WI 54308-8100 • Tel 1-800-424-2432 • www.ki.com

© 2015 Krueger International, Inc. All Rights Reserved • Code KI-60258R2/KI/PDF/0815

Furnishing Knowledge®