
FUNC.

WHERE FUN AND FUNCTION CONNECT

KAYA
FIXED SCREEN


INSTALL INSTRUCTIONS

Kaya Fixed Screen install guide for all sizes.




x1 Kaya Fixed Screen


CONTENTS




Tube Gliders
x4



Aluminum Tube
x2



Adjustable feet
x4



PET Panel
x1


0

Tools you will need:


- Phillips head screw driver
- Metal Saw
- Drill

Safety protection you will need:

- Safety Glasses



1



h = (Floor to ceiling height) - 2" [50mm]

a.
Max Ceiling Height Is 120" [3050mm]
Longer Tubes Available On Request

b.
Slide tubes down into the Kaya Panel.


FUNC.

WHERE FUN AND FUNCTION CONNECT

KAYA
FIXED SCREEN

INSTALL INSTRUCTIONS

2




a.
Ensure tubes are within the PET panel

b.
Insert Glider at the top and bottom of the tube.

c.
Ensure Gliders are flat and straight

3



a.
Insert adjustable feet.

b.
Adjust feet to be able to smaller than the floor to ceiling height.


FUNC.


WHERE FUN AND FUNCTION CONNECT

KAYA
FIXED SCREEN

INSTALL INSTRUCTIONS


2





(Top + Bottom)


a.
Insert Kaya screen into position.
Adjust feet until Kaya panel is tight.



b.
Pre Drill Foot (Top + Bottom)


3

BOTTOM






TOP



Screws are not included-
Installer to supply based
on-site conditions.

a.
Screw and secure feet into
position with bolts.



b.
All done and ready to be used,