
Parts Diagram

Apply™ Task Chair
Armless Chair

May 2014



.XXX = Select Laminate
ARSC includes 12.1020
15.1084.D uses 46.2995.CC
15.1078 uses SIFT.015


Item	Part Number	Item Description	Qty
1	47.0827.XXX	Assembly, Molded Plywood Seat	1
	47.0827.U.XXX	Assembly, Molded Plywood Seat w/ Upholstery	1
2	87.0458.BL	Assembly, Apply Pedestal Spider & Mechanism	4
3	PT.06.6040.BL	Handle, Pedestal	1
4	12.0565	Screw, 1/4-20 x 1/2" Hex Head with Nylok	1
5	15.1084.D	Cylinder, Pneumatic Height Adjustment, Type D	1
	15.1078	Cylinder, Gas Seat Height Adjustment	1
6	46.2995.CC	Base, 5 Blade Pedestal Stool	1
	SIFT.015	Aluminum Base, Sift Task Chair	1
7	09.0440.BL	Caster, 60mm Diameter Hard Floor	5
	09.0441.BL	Caster, 60mm Diameter Soft Floor	5
8	ARSC	Assembly, Replacement Seat Cushion	1
9	12.1020	Screw, #10-24 x 5/8" PTH with Patch	4

©2014 Krueger International, Inc. All Rights Reserved · P0035-0132 · Rev. 1 · Page 1 of 1

Parts Diagram ■

Apply™ Task Stool
Armless Stool

May 2014



.XXX = Select Laminate
ARSC includes 12.1020

Item	Part Number	Item Description	Qty
1	47.0827.XXX	Assembly, Molded Plywood Seat	1
	47.0827.U.XXX	Assembly, Molded Plywood Seat w/ Upholstery	1
2	87.0458.BL	Assembly, Apply Pedestal Spider & Mechanism	1
3	PT.06.6040.BL	Handle, Pedestal	1
4	12.0565	Screw, 1/4-20 x 1/2" Hex Head with Nylok	4
5	15.5550	Ring, Stool Foot	1
6	15.1002.B	Cylinder, Gas Seat Height Adjustment	1
7	46.2995.CC	Base, 5 Blade Pedestal Stool	1
	SIFT.015	Aluminum Base, Sift Task Chair	1
8	09.0440.BL	Caster, 60mm Diameter Hard Floor	5
	09.0441.BL	Caster, 60mm Diameter Soft Floor	5
9	ARSC	Assembly, Replacement Seat Cushion	1
10	12.1020	Screw, #10-24 x 5/8" PTH with Patch	4

©2014 Krueger International, Inc. All Rights Reserved · P0035-0133 · Rev. 1 · Page 1 of 1